

Instrukcje Bezpieczeństwa dla Rozsuwalnej Bariery Ochronnej

Wprowadzenie

Przed rozpoczęciem użytkowania rozsuwalnej bariery ochronnej, prosimy o dokładne zapoznanie się z poniższymi instrukcjami bezpieczeństwa. Stosowanie się do tych wytycznych pozwoli zapewnić bezpieczne użytkowanie produktu oraz ochronę dzieci i zwierząt domowych.

Instrukcje Montażu

- Używaj odpowiednich akcesoriów montażowych dostosowanych do materiału miejsca instalacji.
- Instalacja bez wiercenia nie jest odpowiednia dla następujących powierzchni: ściany gipsowo-kartonowe, betonowe, malowane, tynkowe oraz inne nierówne powierzchnie.
- Upewnij się, że wszystkie elementy montażowe są prawidłowo zamocowane i stabilne przed użytkowaniem bariery.

Bezpieczne Użytkowanie

- Upewnij się, że mechanizm blokady jest zawsze zabezpieczony, gdy bariera jest w użyciu, aby zapobiec przypadkowemu otwarciu przez dzieci lub zwierzęta.
- Zawsze trzymaj dzieci z dala podczas otwierania lub zamykania bariery, aby uniknąć przytrzaśnięcia palców.
- Nie pozostawiaj dzieci bez opieki w pobliżu bariery.

Usuwanie Zagrożeń

- Sprawdzaj regularnie stan bariery i jej komponentów w celu wykrycia ewentualnych uszkodzeń lub zużycia materiału. Nie używaj produktu, jeśli jest uszkodzony.
- Zapewnij, że bariera jest zawsze czysta i wolna od przeszkód, które mogłyby wpływać na jej działanie.

Informacje Dodatkowe

- Produkt jest przystosowany do używania zarówno wewnątrz, jak i na zewnątrz.
- Przeznaczony do użytku w drzwiach, schodach i dużych otworach.
- Przed użyciem w nowych miejscach montażu upewnij się, że produkt jest odpowiednio dostosowany do danej lokalizacji.

Wszelkie pytania lub wątpliwości dotyczące użytkowania produktu prosimy kierować bezpośrednio do producenta lub autoryzowanego dystrybutora.

Retractable Safety Gate



⚠ WARNING

Before assembling and using the gate, please read all of the information below. Failure to follow these warnings and instructions could result in serious injury or death.

1. To avoid serious injury or death, securely install the gate or enclosure and use it according to the manufacturer's instructions.
2. Never use with a child able to climb or dislodge open the door or enclosure.
3. Never leave the child unattended. This product will not necessarily prevent all accidents.
4. Use this product only when the locking/locking mechanism is fully engaged.
5. This product is intended for use with children 6 to 24 months old or small to medium sized pets.
6. Never use with a child able to open or cross the gate.
7. (Incorrect assembly or positioning of the gate can be difficult. Never adjust the handle when the gate is retracting.)
8. This safety gate should NOT be mounted across window openings and the like.
9. DO NOT use the safety gate if any components are damaged or missing.
10. Install this barrier away from heaters and other heat sources.
11. Always check that the gate is locked after closing.
12. If the gate is used at the bottom of the stairs to prevent the child from climbing, it should be placed on the level staircase.
13. If the gate is used at the top of stairs to prevent the child from falling down stairs, it MUST be placed 7.6m (25ft) behind the top step.



14. The safety barrier should be installed between rigid surfaces such as plasterboard, wood or hard walls.
15. Children have died or been seriously injured as a result of improperly installed safety barriers.
16. ALWAYS install and use gates according to the instructions and using all necessary parts.
17. You MUST install mounting hardware to hold the gate in place. Without mounting hardware, the child can get out and escape.
18. NEVER use the gate to prevent a child from approaching the pool.
19. This product will not necessarily prevent all accidents.
20. This product is a deterrent and not a substitute for adult supervision. Never leave children unattended. Check the gate regularly to ensure safe usage.