

Instrukcja bezpieczeństwa użytkowania

Przed pierwszym użyciem należy dokładnie przeczytać i zachować tę instrukcję. Produkt przeznaczony jest dla dzieci od 6. roku życia i powinien być używany wyłącznie zgodnie z przeznaczeniem, pod nadzorem osoby dorosłej.

1. Przeznaczenie i ogólne zasady bezpieczeństwa

- Urządzenie jest przeznaczone do domowej zabawy muzycznej i edukacyjnej.
- Używaj wyłącznie w suchych, bezpiecznych warunkach, z dala od źródeł ciepła, ognia, wody i wilgoci.
- Nie stosuj produktu w sposób odbiegający od instrukcji ani do innych celów niż zabawa i nauka.
- Nie pozwalaj dzieciom bawić się elementami opakowania. Folie, opaski, kartony i inne części opakowania mogą stanowić zagrożenie uduszeniem.

2. Nadzór osoby dorosłej

- Zaleca się, aby pierwsze użycie odbywało się pod nadzorem dorosłego.
- Dorosły powinien kontrolować sposób korzystania z urządzenia, szczególnie przy podłączaniu zasilania, wymianie baterii oraz łączeniu z urządzeniami zewnętrznymi.
- Nie pozostawiaj małych dzieci bez nadzoru podczas zabawy produktem.

3. Bezpieczne użytkowanie

- Przed włączeniem upewnij się, że urządzenie nie ma widocznych uszkodzeń mechanicznych, pęknięć ani luźnych elementów.
- Nie naciskaj przycisków z nadmierną siłą i nie obciążaj urządzenia.
- Nie zasłaniaj otworów głośnika ani innych elementów konstrukcyjnych.
- Nie wkładaj palców, narzędzi ani innych przedmiotów do otworów i szczelin.
- Unikaj upuszczania, rzucania i uderzania urządzenia.

4. Światła, dźwięk i wrażliwość sensoryczna

- Produkt może emitować dźwięki oraz efekty świetlne. Używaj go w umiarkowanym czasie i w odpowiedniej odległości od twarzy dziecka.
- Nie kieruj źródeł światła bezpośrednio w oczy.
- Jeżeli dziecko wykazuje dyskomfort, ból głowy, nadwrażliwość na światło lub dźwięk, natychmiast przerwij zabawę.

5. Zasilanie i baterie

- Do urządzenia stosuj wyłącznie baterie zgodne z wymaganiami producenta.
- Baterie wkładaj zgodnie z oznaczeniami biegunowości (+/-).
- Nie mieszaj baterii starych z nowymi ani różnych typów.
- Nie próbuj ładować baterii jednorazowych.
- Wyjmij baterie, jeśli urządzenie nie będzie używane przez dłuższy czas.
- Natychmiast wymień baterie uszkodzone, rozlane, przegrzane lub skorodowane.
- W razie wycieku baterii nie dotykaj elektrolitu gołymi rękami; unikaj kontaktu ze skórą, oczami i odzieżą.
- Zużyte baterie utylizuj zgodnie z lokalnymi przepisami dotyczącymi odpadów niebezpiecznych.

6. Łączność z urządzeniami zewnętrznymi

- Przed połączeniem Bluetooth lub innym połączeniem bezprzewodowym upewnij się, że urządzenie zewnętrzne jest bezpieczne i sprawne technicznie.
- Nie używaj urządzenia w pobliżu sprzętu medycznego, jeśli może to zakłócać jego pracę.
- Podczas podłączania i odłączania urządzeń zewnętrznych trzymaj ręce suche.
- Nie używaj kabli, adapterów ani akcesoriów uszkodzonych lub niezgodnych z urządzeniem.

7. Higiena i czyszczenie

- Przed czyszczeniem wyłącz urządzenie i usuń baterie, jeśli jest to wymagane.
- Czyść miękką, suchą lub lekko wilgotną ściereczką.
- Nie zanurzaj urządzenia w wodzie i nie używaj agresywnych środków czyszczących, rozpuszczalników ani sprayów.
- Nie dopuszczaj do przedostania się cieczy do wnętrza urządzenia.

8. Przechowywanie i transport

- Przechowuj produkt w suchym miejscu, z dala od bezpośredniego nasłonecznienia, wilgoci i wysokich temperatur.
- Podczas transportu zabezpiecz urządzenie przed uderzeniami i naciskiem.
- Trzymaj produkt poza zasięgiem małych dzieci, gdy nie jest używany.

9. Kiedy nie używać produktu

- Nie używaj urządzenia, jeśli jest uszkodzone, przegrzane, wydziela zapach spalenizny, działa niestabilnie lub wydaje nietypowe dźwięki.
- Nie używaj produktu po zalaniu, upadku z wysokości lub widocznej deformacji.
- W przypadku awarii natychmiast przerwij użytkowanie i odłącz źródło zasilania.

10. Ostrzeżenia dodatkowe

- Produkt zawiera małe elementy i nie jest odpowiedni dla dzieci poniżej 3 lat.
- Zabawa powinna odbywać się z zachowaniem umiaru, aby nie przeciążyć słuchu dziecka.
- Regularnie sprawdzaj stan urządzenia oraz komory baterii.

W razie wątpliwości dotyczących bezpieczeństwa użytkowania należy natychmiast przerwać korzystanie z produktu.

vttech®

Kidi
DJ MIX

Let's get this party started!

Built-in
speaker

Headphone jack
for silent play.

*Headphones not included

Recycling Tips

Learn more at:
www.vtech.co.uk/recycle
In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

*Visit www.recycling.gov.uk to see a list of collection points near you.

TRY ME!
press the
button for
a demo!

Kidi DJ MIX

Fun DJ
turntable
effects!


15 built-in
tracks in
4 styles!

6+
Years




The Bluetooth® word mark and logo are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Vtech is under license. Other trademarks and trade names are those of their respective owners.
© 2011 Vtech. All rights reserved.
Vtech and the Vtech logo are registered trademarks of Vtech.
Packaging must be retained since it contains important information.
Vtech Electronics Europe B.V., Parnassusstraat 22, 6500 DC, Wageningen, The Netherlands.
Vtech Electronics Europe Pty. Limited, Level 6, 32 Albert Road, South Melbourne VIC 3205, Australia.
Vtech Electronics (Australia) Pty. Limited, Level 6, 32 Albert Road, South Melbourne VIC 3205, Australia.
Warning: This toy produces sounds that may trigger epilepsy in sensitive individuals.

Frequency Band: 2402 MHz - 2480 MHz
Maximum RF power: 1.5W (20dBm)
Warning: Not suitable for children under 36 months. Small parts. Choking hazard. Electric toy. Electric shock hazard.



For: 0208 678 9188 (Mon-Fri)
1800 882 101 (Australia and NZ)
www.vtech.co.uk
www.vtech.com.au



Kidi DJ Mix
8811
64752 05 N471
Item No.: 80-547203
Model ID: 5473



Vtech®

Bluetooth

Vtech®

10-in-1

Bluetooth

Kid!
DJ MIX

15 built-in
tracks in
4 styles!

Fun DJ
turntable
effects!

6+
Years

Record
your own
mixes!

Sound Grid
Buttons with
2000+
combinations!

Create your
own sound
effects!

Let's get this party started!

Kid!
DJ MIX

TRY ME!
Press the
button for
a demo!

Kid! DJ MIX

ACADEMY STUDIO DJ PARTY

ROCKS LINE IN AUDIO/USB

Bluetooth



vtech[®]

Let's get this party started!

With Kidi DJ Mix by VTech[®], you can create your own DJ mixes and add cool effects like a real DJ! Explore all of the controls and show your musical creativity as the life of the party! You can even connect your music player (not included) and DJ along to your favourite tracks!



15 built-in tracks in 4 styles

Show your creativity and DJ along to the 15 built-in tracks! Scratch the disc and add in a variety of amazing sound effects just like a real DJ.

Sound Grid Buttons with 2000+ combinations

Play over 2000+ great sound effect combinations on the Sound Grid Buttons and feel just a real DJ on stage!

Fun DJ turntable effects

Show your creativity and select different effects to use with the DJ turntable!

Record your own mixes

Record 3 creations for up to 3 minutes each, so you can listen back and enjoy your performance!

Create your own sound effects

5 dedicated buttons allow you to record your own sound effects to play as you DJ!

Multicoloured Disco light

Get the party going with the Disco light! Choose a light pattern to project as you raise the roof!

Academy mode music game

Test and improve your DJ skills with this fun rhythm game!



DJ track controls

Use the controls to change tracks, change tempo, cross-fade and more!

Connect to your own music player (not included)

DJ along to your favourite tracks via either a Bluetooth[®] connection or a 3.5mm jack audio cable (not included).

Built-in speaker

DJ on stage whilst the built-in speaker plays your mixes aloud to the crowd!

★ Sound Grid Buttons with 2000+ combinations! ★

★ DJ track controls! ★

★ Multicoloured Disco light! ★

Bluetooth[®]

4 AA batteries
(Not included)

(Music player not included)

vtech®

vtech®

Kidi
DJ MIX

Let's get this party started!

DJ along to
your own
music!*



*Music player required to play own music and is not included

VTech's interactive toys
promote **learning!**

Learn more about this and other great
VTech products at

www.vtech.co.uk

www.vtech.com.au

Made in China

10-in-1

15 built-in tracks in
4 styles

Sound Grid Buttons with
2000+ combinations

Fun DJ turntable
effects

Record your own
mixes

Create your own
sound effects

Multicoloured
Disco light

Academy mode
music game

DJ track controls

Connect to your
own music player
(not included)

Built-in speaker

Bluetooth®

Kidi
DJ MIX

15 built-in
tracks in
4 styles!

Fun DJ
turntable
effects!

6+
Years

TRY ME
Press the
button for
a demo!

Kidi DJ MIX
Vtech



vtech®

10-in-1

- 15 built-in tracks in 4 styles
- Sound Grid Buttons with 2000+ combinations
- Fun DJ turntable effects
- Record your own mixes
- Create your own sound effects
- Multicoloured Disco light
- Academy mode music game
- DJ track controls
- Connect to your own music player (not included)
- Built-in speaker

Bluetooth

Kidi
DJ MIX

15 built-in
tracks in
4 styles!

Fun DJ
turntable
effects!

TRY ME!
Press the
button for
a demo!

Kidi DJ MIX

6+
Years