

Instrukcje Bezpieczeństwa dla UKLISS 7 w 1 Pro Airstyler & Ion Hair Dryer

- Upewnij się, że urządzenie jest podłączone do źródła zasilania o odpowiednim napięciu, zgodnym z wymogami producenta - 1200W.
- Nie używaj urządzenia w pobliżu wody, np. w wannie, pod prysznicem czy w wilgotnych pomieszczeniach, aby uniknąć ryzyka porażenia prądem elektrycznym.
- Unikaj blokowania wlotu oraz wylotu powietrza podczas pracy urządzenia, aby zapewnić prawidłowy przepływ powietrza i zapobiec przegrzaniu.
- Nie dotykaj urządzenia mokrymi rękami i upewnij się, że powierzchnie dookoła są suche przed rozpoczęciem stylizacji włosów.
- Podczas użytkowania, trzymaj urządzenie w bezpiecznej odległości od twarzy i oczu, aby uniknąć obrażeń związanych z gorącym powietrzem.
- Przed zmianą nasadki lub po zakończeniu użytkowania, zawsze odłącz urządzenie od źródła zasilania i pozostaw do całkowitego ostygnięcia.
- Nie korzystaj z urządzenia, jeśli kabel zasilający jest uszkodzony. W takim przypadku skontaktuj się z profesjonalnym serwisem w celu naprawy.
- Unikaj używania urządzenia na włosach pokrytych produktami łatwopalnymi, takimi jak lakier do włosów.
- Nie zostawiaj urządzenia podłączonego do źródła zasilania bez nadzoru.
- Przechowuj urządzenie poza zasięgiem dzieci, zwłaszcza podczas pracy i nagrzewania.
- Używaj tylko oryginalnych części i akcesoriów dostarczonych przez producenta, aby zagwarantować bezpieczne i efektywne działanie urządzenia.
- Zapoznanie się z instrukcją obsługi dostarczoną przez producenta przed pierwszym użyciem jest koniecznością, aby zapewnić prawidłowe i bezpieczne użytkowanie.


USER MANUAL

High Speed Hot Air Brush HD-3226

Read instruction manual carefully before use

Before using this product, please read carefully all the instructions and warnings in this manual, and save it for future reference. When using the product, be sure to follow all the basic safety precautions outlined below.

Product Description



⚡ Do not use the product when showering or bathing

SPECIFICATIONS

Power	AC:220Vac 50Hz 1200W,110,000 RPM
Power cord	2m with 360Swivel Cord
Product weight	480G
Packaging weight	2.08KGS
Product Length	10.2 in

HOW TO USE

When using this product to create hairstyles, different hair types require different temperatures and times. It is recommended to test a small section of hair to ensure that you achieve the desired results.

First of all, plug the product into an outlet and push the power button up, which is the power on state. There are three buttons on the top corresponding to: cold wind, speed setting, temperature setting three buttons, each button has three gears, you can choose the right wind speed and temperature according to your needs.

FOLDING FUNCTION: You can rotate the handle to the right where it folds as needed, and there is a locking button on the back of the handle to secure the orientation. You will get a 90° degree folding handle.
NOTE: When you rotating, make sure the holding button on the back of the handle is pointing up.

Negative ion technology function:

Eliminates the frizz. Leaves hair smooth, silky and shiny. Repairs damaged hair. Reduces static. Seals and smooth split ends. Locks in moisture.

Safety Instructions

1. Before connecting the device, make sure that the voltage shown on the label matches the local voltage.
2. If the cord is broken, to avoid danger, the manufacturer's service organization or a similarly qualified center must replace it.
3. Use the hair dryer brush in the bathroom even if it is switched off. The proximity to clothes may cause danger, so be sure to unplug it after use.
4. For further protection, it is recommended that an earth leakage circuit breaker (ACD) be installed to detect leakage currents up to 30MA to prevent electric shocks.
5. WARNING, Don't use this appliance near a bathtub, shower facility, scrubber, or other container of water.
6. Do not use the hair dryer for any other purpose not described in this manual.
7. Please do not place it within reach of children or let children play with it.
8. This product is a high-temperature product. Please use it carefully when styling to avoid accidents such as burns.
9. Do not let the heated surface come into contact with your hands or exposed skin to avoid burns.
10. This equipment should be used wisely by following proper supervision or instruction; if you understand the risks, children and people who lack experience and knowledge or who have reduced physical fitness, strong or mental capacity may not use it.
11. When the negative ion generator is working, it will produce a sizzling sound, which is a normal phenomenon. The time required for hair styling varies depending on individual hair quality and styling technique.

WARNING: FOR YOUR SAFETY, UNPLUG THE POWER WHEN YOU DON'T USE IT. BECUASE THERE IS STILL POWER IF YOU JUST SWITCHIT OFF.

USING TIPS

Including the following:

1. Always unplug the blow dryer from the power clip before cleaning or not using the hair dryer.
2. To prevent the risk of electric shock, do not immerse the appliance in water or other liquids
3. Do not spray the product when using the hair dryer brush.
4. Do not turn the hair dryer on when not in use.
5. Do not use other accessories not provided.
6. Never use while bathing!
7. To prevent the unit from malfunctioning, do not block the open air inlet and exhaust ports.
8. However, if the air flow is accidentally interrupted during use, the built-in safety circuit breaker will automatically shut off the unit. After a few minutes of heating, the power to the hair dryer will automatically turn on again.
9. Do not place the open air intake port close to your hair to prevent the appliance from pulling on your head of hair.
10. Store the appliance in a cool and dry place. Do not use the appliance when your hands are wet!

CAUTION

Never pull or twist the power cord.
Do not twist the power cord around the appliance.
Always check the power cord for damage.
Stop using it immediately if damage is visible, or if the equipment stops or operates intermittently.

Thank you for choosing us.
Please keep this manual for future

Reference. If you decide to give away this product, please do it together with this manual. Please note actual product may vary from the digital representation in terms of shape and color.